
Change presser foot

Full guide


1 Switch off



Step help

Switch off before changing the foot.

2 Raise the needle




Step help

Turn the handwheel toward you until the needle is highest.

Change presser foot


3 Raise the foot



Step help

Lift the lever behind the needle.


4 Remove the foot



Step help

Pull the foot straight down. Use the rear release button if fitted.


5 Align the pin



Step help

Place the new foot’s crossbar directly beneath the holder’s notch.

6 Snap it in




Step help

Lower the lever. The holder snaps onto the crossbar.

Change presser foot


7 Check the attachment



Step help

Raise the lever. The foot should lift with the holder.

8 Check needle clearance



Step help

Select your stitch. Turn the wheel slowly; the needle must clear the foot.